

Germination Station™ Instructions

- 1.) Lay down the heat mat on a smooth surface (not cement or steel- it draws too much heat away).
- 2.) Place the cut-kit tray directly on top of the heat mat.
- 3.) Fill the tray with your favorite growing medium and seeds, moisten with water (ideally with PH levels around 5.5-6.0).
- 4.) Place the dome on top of the tray. Either offset the dome slightly or place a small cut on the top of the dome to allow some air flow.
- 5.) Do not over water. Keep moist, not wet, and do not allow to dry out completely.
- 6.) Allow 4-7 days for seeds to germinate.
- 7.) Once plants are several inches tall, transplant and watch them grow...

Hydrofarm Gardening Products

<http://www.hydrofarm.com>

MADE IN THE USA