

ACTIVE AIR™

FLEXIBLE AIR DIFFUSER

CHARACTERISTICS

- The Hydrofarm Flexible Air Diffuser allows you to bend it into any shape needed.
- It provides uniform oxygen dispersal throughout its length.
- Ideal for oxidation of aquariums and reservoirs as well as decorative use.


DIRECTIONS

Attach 4mm rubber hose from air pump to the flexible air diffuser, then submerge into water and turn power on for bubble dispersion.

To ensure proper distribution of air, please ensure that:

- a) the stone is clean
- b) the stone is at a consistent depth in the water
- c) sharp bends are avoided

Failure to maintain a consistent depth across the length of the stone, or overly-sharp bends, can cause a lack of consistent air distribution. If you are experiencing a lack of air distribution in certain areas of the stone try modifying the bends, verifying the stone's depth, or cleaning the stone as instructed on the packaging.



MAINTENANCE

After a period of time, the holes in the diffuser may become blocked. Immerse the hose in hot water for 8 minutes, then rub the hose with a brush or cloth to clean.