


To add or remove a burner to Selene Series CO² Generators

1



Apply a small amount of pipe thread sealant to middle of burner threads and tighten snugly into burner bar by using 1/2" wrench

2



Apply a small amount of pipe thread sealant to middle of plug threads and tighten snugly into burner bar by using enclosed hex wrench

DO NOT OVER TIGHTEN