

## Bluelab Commercial Truncheon™ Troubleshooting

### Problem

### Corrective Action

**Commercial Truncheon turns off before reading taken.**

Take out of solution for 3-5 seconds. Dip in solution again and take reading.

**Commercial Truncheon not lighting up when dipped in solution.**

Clean the probe (see page 2 of Commercial Truncheon Manual). If this is unsuccessful, replace batteries (page 2 of Commercial Truncheon Manual).  
“Do not use rechargeable batteries.”

**Commercial Truncheon gives low readings.**

Clean the probe (see page 2 of Commercial Truncheon Manual).  
Ensure unscented cleaner is used, such as plain ‘Jif’/‘Soft Scrub’/‘Liquid Vim’.