

Bluelab Truncheon™ Troubleshooting

Problem	Corrective Action
Truncheon turns off before reading taken.	Take out of solution for 3-5 seconds. Dip in solution again and take reading.
Truncheon not lighting up when dipped in solution.	Clean the probe (see page 2 of Truncheon Manual). If this is unsuccessful, replace batteries (page 2 of Truncheon Manual). "Do not use rechargeable batteries."
Truncheon gives low readings.	Clean the probe (see page 2 of Truncheon Manual). Ensure unscented cleaner is used, such as plain 'Jif'/'Soft Scrub'/'Liquid Vim'.