

# *Standard Reference Solution @ 25°c*

*for calibration of  
EC and PPM  
Conductivity Meters*

*Specimen*

## **INSTRUCTIONS**

Pour reference solution into a clean container. Refer to meter manufacturer's instructions. Immerse EC/PPM meter electrode in Standard Reference Solution. After one minute adjust calibration so that the meter indicates the correct EC or PPM. Use the solution only once, then discard. Never pour used solution back into this bottle. Calibrate your meter frequently.

*1500 ppM (NaCl scale)*

*2190 ppM (442 scale)*

*2930 S (microSiemens)*



**KEEP OUT OF REACH  
OF CHILDREN**

Manufactured by

 **GH**  
**genhydro.com**

PO Box 1576, Sebastopol, CA 95473, USA



946 ml (1 Quart)