



Universal CO₂ MONITOR

OPERATION MANUAL

IMPORTANT SAFETY INFORMATION • DO NOT DISCARD


www.hydroinnovations.com

PRODUCT OVERVIEW

Hydro Innovations is now offering a high quality yet extremely affordable CO₂ monitor. The product features a maintenance-free SenseAir® brand gas detector, which after extensive testing we have found to be the most accurate sensor available. The cost savings are not as a result of cutting corners on the accuracy or function of the unit, it is because our unit is simplified and lacks a lot of the frequently unused bells and whistles that other monitors have. Our monitor is not adjustable and comes preset to turn on at 1300 PPM and off at 1500 PPM. Simple indicator lights show the current CO₂ levels instead of a digital screen. Our monitor comes with a piggyback plug, allowing it to be used with any brand generator. We also supply our easy-mount wall bracket to make installation as easy as it can be. The simplicity of our monitor makes it the most user-friendly CO₂ monitor available.



CO₂ Monitor Unit



Piggyback Plug

FEATURES

- ❖ Simply all you need to regulate CO₂.
- ❖ Programmed to turn on at 1300 ppm and off at 1500 ppm.
- ❖ Indicator lights to show CO₂ levels.
- ❖ Easy to install with our wall mount bracket.
- ❖ 120 volt switched piggyback cord.
- ❖ Quality SenseAir® brand CO₂ detector.
- ❖ Self calibrated and maintenance free.

WARNING

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING

For the best accuracy do not place the monitor in direct lighting from HID lamps. Direct light interferes with the infrared sensor's ability to read properly. Don't shake or hit the CO₂ indicator/controller excessively in shipment or in mounting to protect the internal infrared CO₂ sensor and receiver from damage or misalignment. Do not place the CO₂ monitor in outdoor conditions and never expose directly to moisture. Avoid using the monitor in extremely high humidity levels especially for long periods of time. This is a sensitive electronic device and needs to be treated as such to maintain accuracy. Make sure that the wires for the piggyback plug are seated in the grooved cord grip on the back of the mounting bracket before installation. Do not pull on the piggyback cord wires, this could cause damage to the monitor and cause it not to work properly.

- 1** Mount CO₂ monitor inside the garden approximately 48" off the floor and out of direct lighting from HID lamps. Use the supplied wall mount bracket and supplied screws.

Make sure that the wires for the piggyback plug are in the groove on the back so that they do not interfere with mounting. The wall bracket does not need to be removed from the monitor for installation.
- 2** Once the monitor is mounted, plug the power adapter in to a 120v plug receptacle and then plug the DC male end of the cord in to the female DC jack of the CO₂ monitor. This power adaptor supplies power to the monitor. Once plugged in the monitor should come on, taking a few minutes to stabilize.
- 3** Place the monitor in an area that has natural CO₂ levels (less than 500 ppm) and allow it acclimate for 48hrs for the best accuracy. Please note that CO₂ levels inside your home are usually higher than natural CO₂ levels especially if gas appliances are present. Typically a garage a room with an open window is fine, but never put the monitors in the outdoor elements. The monitor should stabilize to 500 ppm (the first light on the monitor) for at least 24hrs before using.
- 4** Plug the piggyback cord in to a constant 120v outlet.



Universal CO2 MONITOR

www.hydroinnovations.com



If you have any additional questions or concerns regarding this, or any HYDRO INNOVATIONS product, please contact us through our website www.hydroinnovations.com or call: 512-285-6413



SPECIFICATIONS

Power supply	12VAC/12VDC ± 10%
Consumption	1.0 W Max
Gas sensor	Carbon Dioxide: Non-Dispersive Infrared Detector (NDIR) ABC Logic Self Calibration (default: ineffective)
CO2 measuring range	0~2,000ppm
Accuracy @25 (77) 2000ppme	±40ppm + 3% reading
Stability	<2% of FS over life of sensor
Non linearity	<1% of FS
Response time	<2 minutes for 90% step change Warm up time for each turning-on 48 hours (first time) 10 minutes (operation)
Dry contact output	<120VAC/30VDC 6A switching current (resistance load), Four CO2 values selectable to control the relay by jumpers
6 LED lights	#1 green light on when CO2 is less than 700 ppm #2 green light on between 700 ppm and 900 ppm #3 green light on between 900 ppm and 1100 ppm #4 green light on between 1100 ppm and 1300 ppm #5 green light on between 1300 ppm and 1500 ppm #6 green light on for 1500ppm or higher
Storage conditions	Storage conditions -40°F to 150°F
Operation conditions	32°F to 122°F with less than 95% humidity 110g/100mm(H) × 80mm(W) × 24mm(D)